

| Individual Parts | | | | | Assembled Panels | | |
|----------------------------------|--|-----|-------------------------|-------|----------------------------|---|-----|
| Part # | Description | QTY | | Holes | Part # | Description | QTY |
| F1 | Bench Support | 2 | 2 x 3 x 17-3/4 | 0 | FSRP | Front Side - Right Panel | 1 |
| F2 | Porch Roof Support | 2 | 2 x 3 x 41-7/8 | 0 | FSLP | Front Side - Left Panel | 1 |
| F3 | Frame Board | 2 | 2 x 3 x 13-1/4 | 0 | RSRP | Right Side - Right Panel | 1 |
| F4 | Frame Board | 2 | 2 x 3 x 46-1/2 | 2 | RSCP | Right Side - Center Panel | 1 |
| F5 | Frame Board | 1 | 2 x 3 x 42-1/2 | 0 | RSLP | Right Side - Left Panel | 1 |
| L1 | Sculptured Rail | 2 | 1 x 5 x 46-1/2 | 0 | LSLP | Left Side - Left Panel | 1 |
| L2 | Right Sculptured Rail | 1 | 1 x 5 x 48-1/2 | 0 | LSRP | Left Side - Right Panel | 1 |
| L3 | Left Sculptured Rail | 1 | 1 x 5 x 48-1/2 | 4 | BSRP | Back Side - Right Panel | 1 |
| L11 | Shelf Support | 3 | 1 x 5 x 9 | 0 | BSCP | Back Side - Center Panel | 1 |
| M11 | Window Trim | 4 | 1 x 4 x 15 | 0 | BSLP | Back Side - Left Panel | 1 |
| M12 | Door Trim | 2 | 1 x 4 x 37 | 0 | DP | Door Panel | 1 |
| M15 | Outside Shelf Board | 1 | 1 x 4 x 46-1/2 | 6 | RS | Right Shuttler | 2 |
| M16 | Outside Shelf Board | 1 | 1 x 4 x 46-1/2 | 6 | LS | Left Shutter | 2 |
| M20 | Arm Rest | 2 | 1 x 4 x 12 | 3 | GE | Gabel End | 2 |
| M21 | Porch Rail | 1 | 1 x 4 x 48-1/2 | 4 | IS | Inside Shelf | 1 |
| M30 | Window Trim | 1 | 1 x 4 x 22-3/4 | 0 | TB | Toy Box | 1 |
| O1 | Porch Rafter | 2 | 1-1/2 x 1-1/2 x 16-9/16 | 0 | RC | Ridge Cap | 1 |
| P1 | Porch Support | 1 | 1-1/4 x 2 x 48-1/2 | 6 | PSR | Porch Seat - Right Side | 1 |
| R1 | Roof Slat | 18 | 1-1/4 x 6 x 54 | 0 | PSL | Porch Seat - Left Side | 1 |
| S2 | Shutter Stop | 3 | 3/8 x 2 x 2 | 2 | WB | Window Box | 1 |
| U1 | Stool Seat | 2 | 1-1/2 x 7 x 7 | 3 | PR | Porch Rail | 2 |
| Y33 | 32" L x 1.5" W x 1/8" Thick - w/ 4 Holes | 1 | | | | | |
| 6508CONT | 6508 Contents Sheet | 1 | | | | | |
| 6508-99 Accessory Kit Box | | | | | HD6508 Hardware Bag | | |
| Y9-B | 2" x 1" Metal Bracket | 4 | | | Z5-1.25HB | 5/16-18 x 1-1/4" Hex Head Bolt | 5 |
| WD | Wood Dowel - 1" x 14-1/4" Long | 6 | | | Z5-3LS | 5/16 x 3" Lag Screw | 5 |
| 650801 | Wooden Door Knob w/ hardware | 1 | | | Z5-.625STN | 5/16-18 x 5/8" LONG Spiked Tee Nut | 5 |
| 650802 | Door Hinges w/ hardware | 10 | | | Z5-.75FW | 5/16 SAE Flat Washer - 11/16"OD x 11/32" ID | 20 |
| 650804 | Magnetic Catch w/ hardware | 1 | | | Z5-.625ITLW | 5/16 Internal Tooth Lock Washer - 19/32" OD | 10 |
| ALUMID | Aluminum ID Plate | 1 | | | Z4-.75PTH | 1/4-20 x 3/4" Phillips Truss Head Bolt | 9 |
| HD6508 | Hardware Bag - Woodridge Playhouse (see Hardware Bag breakdown) | 1 | | | Z4-.75PBN | 1/4-20 x 3/4" LONG Phillips Barrel Nut | 9 |
| 6508INST | 6508 Instruction Booklet | 1 | | | Z4-.625ITLW | 1/4 Internal Tooth Lock Washer - 15/32" OD | 10 |
| | | | | | Z8-2WS | #8 x 2" Type 17 w/nibs Wood Screw | 53 |
| | | | | | Z8-1.5WS | #8 x 1 1/2" Type 17 w/nibs Wood Screw | 65 |
| | | | | | Z8-1.25WS | #8 x 1 1/4" Type 17 w/nibs Wood Screw | 162 |
| | | | | | Z8-.75WS | #8 x 3/4" Modified Truss Washer Head Screw | 10 |